
# DATABASE & DASHBOARD

IoT CEPT Internship

28 May 2025


# **System Overview**



# What is database?

A collection of data organized for efficient

- Storage
- Management
- Update
- Retrieve



# Why you need database?








- Fast, organized data storage and access
- Secure, accurate data handling
- Scales easily, supports multiple users
- Reliable backup and automation



# What is dashboard?


A dashboard is a visual interface that displays key information and data in an organized and easy-to-digest format








# Why you need dashboard?











- Turn raw data into visual formats
- Highlights trends and patterns
- •Improves communication for non-technical audiences
- Enable real-time monitoring



# Docker



- This Photo by Unknown Author is licensed under <u>CCBY-S</u>
- An open platform for developing, shipping, and running applications.
- Docker provides the ability to package and run an application in a loosely isolated environment called a container.
- •Containers are lightweight and contain everything needed to run the application

To be continue...

# What is a Container and how to run it? Hands-on Guide

Let's follow the guide from

https://docs.docker.com/guides/walkthroughs/what-is-a-container/


https://docs.docker.com/guides/walkthroughs/run-a-container/

https://docs.docker.com/guides/walkthroughs/run-hubimages/

https://docs.docker.com/guides/walkthroughs/publish-your-image/


Docker?

Step 1: Open the terminal



Docker?

Step 1: Open the terminal



Docker?


#### Step 2:

Navigate to the folder with

docker-compose.yml


by running following command in the terminal

cd <YourDockerComposeFolder>




# How to run database and dashboard in Docker?

### Step 3: Run docker compose up -d



Docker?


If it works, you will see 2 containers running in the Containers tab



# Check if database can be access?


Step 1:

Open
timescaledb
container in
the Containers
tab




# Check if database can be access?

Step 2:
Go to Exec tab




# Check if database can be access?



# Check if dashboard can be access?


## Step 1:

In the grafana container row, click the number at the Port(s) column



# Check if dashboard can be access?

# Grafana User Interface (UI)



# Done!

Now you have database and dashboard running on your computer

# Next!

we'll take a quick look at database and dashboard

# Relational Database Overview






- Relational Database is a type of database that organizes data into tables
- A database can have multiple tables


students			
student_id Row	name	birthday	
6630000121	John	1/1/2004	
6630000221	Mary	2/2/2004	

Column




# Postgres Database Command

#### \dt list tables



#### No table exists



#### 1 table named students

# What is SQL?

SQL (Structured Query Language) is the standard language used to communicate with a relational database

# **Today SQL command**

- CREATE DELETE
- •INSERT •DROP
- SELECT

# SQL CREATE table

sensor_data			
time	sensor_id	temperature	humidity
'2025-05-25 08:30:00+07'	1	22.5	45.2
'2025-05-25 08:35:00+07'	1	23.1	47.8

sensor_data		
Column	Data type	
time	TIMESTAMPTZ	
sensor_id	INTEGER	
temperature	FLOAT	
humidity	FLOAT	

#### **Data type**

• Character: Dave → VARCHAR(n)

• Numeric: 15  $\rightarrow$  INTEGER, 3.1415  $\rightarrow$  REAL

• Date/Time: '2004-10-19 10:23:54'  $\rightarrow$  TIMESTAMP '2004-10-19 10:23:54+02'  $\rightarrow$  TIMESTAMPTZ

Boolean : false → BOOLEAN

# SQL CREATE table

```
CREATE TABLE table name (
          column_1 datatype_1,
          column_2 datatype_2,
          ...,
          column_n datatype_n
```

sensor_data			
time	sensor_id	temperature	humidity

); Don't forget to end SQL command with semicolon (;)

#### Try create sensor\_data table with following column name and data type

sensor_data		
Column	Data type	
time	TIMESTAMPTZ	
sensor_id	INTEGER	
temperature	FLOAT	
humidity	FLOAT	

#### Check created table by \dt command

```
postgres=# \dt

List of relations

Schema | Name | Type | Owner

public | sensor_data | table | postgres

(1 row)
```

# SQL INSERT data

```
INSERT INTO table name (column_1, column_2, ..., column_n) VALUES

(data_column_1, data_column_2, ..., data_column_n),

(data_column_1, data_column_2, ..., data_column_n),

...,

(data_column_1, data_column_2, ..., data_column_n);
```

Don't forget to end SQL command with semicolon (;)

## Try insert following sample data

```
INSERT INTO sensor_data (time, sensor_id, temperature, humidity) VALUES
('2025-05-25 08:30:00+07', 1, 22.5, 45.2),
('2025-05-25 08:35:00+07', 1, 23.1, 47.8),
('2025-05-25 08:40:00+07', 1, 22.8, 46.0),
('2025-05-25 08:45:00+07', 1, 24.3, 44.5),
('2025-05-25 08:50:00+07', 1, 23.7, 48.1);
```

## SQL SELECT data

### To select specific column

```
SELECT column_1, column_2, ..., column_n FROM table name;
```

#### To select all column

SELECT \* FROM table name;

Don't forget to end SQL command with semicolon (;)

#### Select time and temperature columns

#### Select all columns

postgres=# s	select * from	n sensor_data	;	
ti	ime	sensor_id	temperature	humidity
		-+	<b></b>	+
2025-05-25	01:30:00+00	1	22.5	45.2
2025-05-25	01:35:00+00	1	23.1	47.8
2025-05-25	01:40:00+00	1	22.8	46
2025-05-25	01:45:00+00	1	24.3	44.5
2025-05-25	01:50:00+00	1 1	23.7	48.1
(5 rows)				




# Step 1:

Access Grafana UI, then log in using default user and password:


User: admin


Pass: admin



# Step 2:

Go to Add new connection in the Connections drop down tab, then search for PostgreSQL and Add new data source






# Step 3:


Enter Name, Connection and Authentication of the database then Save & test


#### Connection parameters




# Step 4:

Go to Dashboards tab, Add visualization and select our data source then query the data in code section and save dashboard







# How to connect database using python

Use connect\_postgres.py in database-and-dashboard folder

```
import psycopg2
                                                        Connection parameters
CONNECTION = "postgres://postgres:password@localhost:30000/postgres"
with psycopg2.connect(CONNECTION) as conn:
    with conn.cursor() as cur: # use the cursor to interact with your database
        cur.execute("SELECT version();")
        version = cur.fetchone()
        print(version)
```

PROBLEMS OUTPUT DEBUG CONSOLE <u>TERMINAL</u> PORTS TEROSHDL: LOG REPORT TEROSHDL: TIMING



# How to insert data in database using python

```
import psycopg2
# Data to be inserted
data = ('2025-05-25 08:55:00+07', 1, 30, 60)
# SQL INSERT statement
insert query = """INSERT INTO sensor data
                (time, sensor_id, temperature, humidity)
                VALUES (%s, %s, %s, %s);"""
CONNECTION = "postgres://postgres:password@localhost:30000/postgres"
with psycopg2.connect(CONNECTION) as conn:
    with conn.cursor() as cur:
        cur.execute(insert query, data)
    conn.commit()
print(f"Inserted row: {data}")
```

Use insert\_postgres.py in database-and-dashboard folder

Try check the inserted data using select command or dashboard

PS C:\Users\User> & C:/Users/User/AppData/Local/Programs/Python/Python312/python.exe c:/Users/User/Desktop/timescaledb/insert\_postgres Inserted row: ('2025-05-25 08:55:00+07', 1, 30, 60)

# SQL DELETE data

DELETE FROM table\_name;

Don't forget to end SQL command with semicolon (;)

Delete sensor\_data table and see what happen with the dashboard

# SQL DROP table

DROP TABLE table\_name;

Don't forget to end SQL command with semicolon (;)

Drop sensor\_data table and see what happen with table in the database \dt

# To receive data from ESP32, recreate the sensor\_data table


```
CREATE TABLE sensor_data(
   time TIMESTAMPTZ,
   sensor_id INTEGER,
   temperature REAL,
   humidity REAL
);
```

# Combine

ESP32(subscribe\_mqtt.py)

and

Database & Dashboard (insert\_postgres.py)



# Which one is your project?

